



NOTE(S):

1. WALKING BEAM BREAKER ASSEMBLY IS TO BE INSTALLED IN THE CONTROL PANEL. GENERATOR PLUG SHALL BE MOUNTED IN A CONVENIENT LOCATION ON THE SIDE OF THE MAIN CONTROL PANEL. PROVIDE DETAIL OF PROPOSED ARRANGEMENT WITH SUBMITTAL PACKAGE FOR APPROVAL BY MPW ELECTRICAL DEPT.
2. A SERVICE DISCONNECT SHALL ALWAYS BE PROVIDED TO DISCONNECT THE ELECTRICAL UTILITY (METER) FROM THE MPW EQUIPMENT. THE DISCONNECT SHALL BE LOCATED JUST AFTER THE UTILITY METER (NO EXCEPTIONS)

MOUNT PLEASANT WATERWORKS
PUMP STATION GENERATOR HOOKUPS

APPROVED BY:

MPW

SCALE:

NTS



DATE:

OCT 2013

REVISED:

OCT 2013

DRAWING NO.

WW-28